



Following the typical assembly guidelines from the Titan installation manual the riser system will be installed between the base plate and the bottom of the sliding gate operator. This will occur between steps 3 and 4 of the typical installation.



1. Install the original base plate provided with the Titan kit (Step 3 of Manual)

2. Sit the riser blocks on the base plate, each should be aligned with the bolt down holes in the base plate. Sit the Sliding gate operator on top of the blocks.

3. Using the original washers and spring washers from the Titan kit (Step 4 of Manual) install the sliding gate operator to the base plate using the new M10 bolts.

